













## Vehicle Identification/Recognition




## Accessing Vehicle



 Supplemental Restraint System Control Module (SRSCM)	 Airbag	 Airbag Gas Inflators
 High voltage cable	 12V Battery Disconnect	 Air-conditioning line
 Low Voltage Disconnect For High Voltage	 Seat belt pretensioner	 Ultra-High Strength Steel
 High Voltage Battery	 Air-conditioning component	

## Disabling Vehicle



## Vehicle Towing Information

*Tow the vehicle using a flat bed or using wheel dollies. Never tow the vehicle with the front or rear wheels on the ground*



**For further information, please refer to the Emergency Response Guide (ERG).**

Applicable to Elantra Hybrid vehicles first sold in the United States.	ID. No.	Version No.	Page
	KMH-CN7 HEV	01.2021.09	2 of 2